



View with ease using our LED Flex Light. The gooseneck arm is extremely flexible and holds its positioning. It offers a crisp clean white light with high brightness and low energy consumption.

Simply slide it into the Accessory Dock, and push the on/off button. Requires 3 "AAA" batteries (not included).

LED FLEX LIGHT

